

Media Master A5200 Telnet Command Code V1.0

(Valid after version S5.19.1014xx)

Telnet network port is 23

Telnet user name and password is reach / reach

Feedback Information:

“success” indicates the operation is done successfully;

“failed” indicates the operation is done unsuccessfully

(1) Start record:

tctrl device record:start

Feedback:

success

failed

(2) Stop record:

tctrl device record:stop

Feedback:

success

failed

(3) Obtaining device status

tctrl device record:status

Feedback:

record state:stopped

record state:recording

(4) Obtaining device HDD information

tctrl device disk:infor

Feedback:

Disk free space:xxxGB